zerorez®

Upholstery Pre-Spray

IMPORTANT NOTICE TO PURCHASER: The manufacturer and seller warrant that the chemical contained herein conforms to its standard specifications. Seller's and manufacturer's liability for any and all losses or damages resulting from any cause whatsoever shall in no event exceed the purchase price of this product, with respect to which losses or damages are claimed. Before using, user shall determine the suitability of this product for the intended use, and user assumes all risk and liability whatsoever in connection therewith. The manufacturer and seller make no representation or warranty, including merchantability or any other kind, expressed or implied. The foregoing may not be altered except by written agreement by officers of the manufacturer.

UPHOLSTERY PRESPRAY is a unique product formulated specifically for the Zerorez System. This acidic pre spray is effective on all types of soils, oils and greases when extracted with Empowered Water and is safe to use on synthetic and natural fibers including cotton and wool.

DIRECTIONS

WATER KEY

= Tap Water

- Pre-test to ensure fabric is wet cleanable.
- Pre-test in an inconspicuous area for color loss or color migration. If color transfer occurs, consider alternate process for color sensitive pieces.
- Dilute 1:8 with tap water for normal soiling or 1:4 with tap water for heavy soiling.
- Spray evenly over surface.
- For area rugs or wool carpet, agitate thoroughly with ZrLifter using soft (wool) brushes.
- For upholstery, agitate thoroughly with hand held horse hair brush.
- Extract with "Empowered Water" – Normal extraction only. Avoid extensive applications or over wetting.
- Repeat previous steps if needed.

CONTAINS

Water (CAS# 7732-18-5), Proprietary blend of acidic builders, Proprietary blend of non-ionic surfactants, Sodium Xylene Sulfonate (CAS# 1300- 72-7), Orange Oil (CAS# 8028-48-6).

WOOL BALANCE

D0821GL

WARNING

Keep out of reach of children.

HAZARD STATEMENTS:
Causes serious eye irritation. Causes skin irritation.

PRECAUTIONARY STATEMENTS:
Wash face, hands and any exposed skin thoroughly after handling. Wear eye protection/ face protection. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. If eye irritation persists: Get medical advice/attention. IF ON SKIN: Wash with plenty of soap and water. If skin irritation occurs: Get medical advice/ attention. Take off contaminated clothing and wash before reuse.

12577 South 265 West, Suite 3A
Draper, UT 84020
www.zerorez.com

Upholstery Pre-Spray